

INSTALLATION & MAINTENANCE

GENERAL INSTRUCTIONS

OFF-LOADING

During off-loading inspect fans for damage. If the casings, cowls or impellers are damaged, notify your local Fantech distributor immediately.

Fantech cannot be held responsible for any loss or damage incurred to goods during transport, off-loading or on site.

SITE STORAGE

The fans must be stored in a clean, dry, protected and vibration-free area. The fan impellers should be rotated daily to prevent bearing damage. Failing to follow these instructions may void the warranty.

MAINTENANCE

Install fans and accessories to allow service access for maintenance and for the replacement of assemblies and component parts, without disturbance of other items of plant and building elements.

Most motors are fitted with sealed-for-life bearings which are maintenance-free. It is recommended that fans be inspected initially at 3-monthly intervals, to clean the blades and motor and to check for tightness of fastenings.

Where fans are used for kitchen exhaust or other applications where the air contains high amounts of dust, residue and other contaminants, fans should be cleaned and maintained at more frequent intervals appropriate for the application.

Motor overloads/contactors should also be inspected to ensure correct operation.

Should external lubricators be fitted, please refer to **LUBRICATION INSTRUCTIONS** in the 'Installation and Maintenance' instructions included with each fan.

If the fans are belt driven, check pulley alignment and belt tension before starting the fan. Belt tension must be checked 2 - 4 weeks after start-up.

MOTORS

All standard motors are suitable for operation in air temperatures between -20°C and +40°C. If higher temperatures are required, contact your local Fantech supplier.

Standard motors are **not** suitable for handling saturated air containing water droplets or for some corrosive fumes. For severe applications, special motors and finishes may be required. Customers are requested to discuss these applications with our sales engineers to ensure a fan suitable for the application is selected.

WARNING - Failure to do so could void warranty.

ELECTRICAL

SUPPLY

Read the fan data label to determine the number of phases and amperage drawn by the unit. Check that the available supply is suitable.

EARTHING

All fans must be earthed in accordance with AS/NZS3000:2007 and local supply regulations.

WIRING

Wiring must be in accordance with AS/NZS3000:2007 and local supply regulations. Wiring diagrams are provided with all fans. Wiring diagrams are shown on pages M-6/9.

PROTECTION


Fuses in the circuit should be regarded as protecting the wiring only against short circuit, they are not suitable for overload protection. Fuses must be able to carry starting loads and these can be taken as a minimum of six times the running current for 25 seconds.

All three-phase motors must be provided with differential action, single-phasing protection and overload current protection. Failure to provide single-phasing protection will void warranty.

Motors fitted with thermistor or thermostatic protection should have these wired into the starting contactors' control circuit to interrupt motor power supply on winding temperature rise.

Wires marked 'TK' are for internal thermal contacts which can be wired directly into the contactor controller circuit. Alternatively, thermal protection devices can be installed into the control circuit therefore negating the need to use the 'TK' contacts. Failure to connect thermal protection devices will void warranty.

DIRECTION OF ROTATION



The correct rotation and direction of air flow is shown on each individual fan. If backward-curved centrifugal fans rotate in the wrong direction, the motor may overload and the motor warranty will be void.

To change the direction of rotation on three-phase motors, interchange any two supply leads. All single-phase motors will rotate in the correct direction when correctly connected.

STARTING

All fans are suitable for direct-on-line starting by switch or automatically by contactor up to and including 5.5kW. The number of starts should be limited to no more than four per hour or, in the case of motors of less than 1kW, no more than eight starts per hour. This would be subject to local supply regulations.

Check List

- check power supply
- check fan is free to rotate
- check overloads are fitted
- ensure ductwork is free of debris
- check rotation of fan
- check the motor amperage draw does not exceed nameplate rating

SAFETY

Rotating fan impellers can be a danger to personnel.

The following precautions must be taken:-

- electrically isolate the fan motor prior to undertaking any work.
- regularly check impeller fasteners for tightness.
- where fans are accessible to personnel or directly exposed to habitable areas, it is the responsibility of the installers to ensure that fans will have guards which comply with the latest Australian Standard AS4024.1 safeguarding of machinery.
- prior to fan start-up, ensure loose debris will not be sucked into the fan. All ductwork should be clean.

INSTALLATION INSTRUCTIONS

Important Notes:

With all horizontally mounted axial fans it is preferable that the fan is installed with the motor mounted on top of the motor plate. ie. not suspended under the motor plate.

For outside installations, IP66 rated conduit and fittings must be used.

To obtain rated performance, the following recommendations should be followed:-

Duct Mounted Fans - General

- inlet and outlet ductwork should be free from obstructions.
- duct transitions should be a maximum of 60° inlet/15° outlet.
- avoid sharp bends on inlet or outlet.
- do not use ductwork smaller in area than the fan.
- flexible duct connections should be taut.
- ductwork connections should be well aligned.
- inlet cones must be fitted to free inlet applications.
- ensure that the fan orientation is correct for the required air flow direction.

Belt-Driven Product

- pulleys must be correctly aligned.
- belts must be correctly aligned and tensioned.
- tension must be checked 2-4 weeks after start-up.

Roof Ventilators

- ensure that upstands are flat and true.
- maximum angle of upstand or curb 30°
- fix a sealing strip of neoprene to the top of the upstand to prevent air leakage.
- fit an electrical compression gland to the roof cowl in an appropriate location and pass the electric cable through as the roof cowl is fitted.
- ensure the electric cable is not pinched prior to securing the cowl to the upstand.
- the roof cowl should be secured with roofing screws through the side skirt midway through the skirt.
- inlet ductwork should be free from obstructions.
- avoid sharp bends at the inlet.
- **vertical discharge axial roof units: ensure the damper flap hinge points down the slope of the roof.**

LUBRICATION INSTRUCTIONS

Most Fantech products are fitted with sealed-for-life pre-lubricated bearings which do not require maintenance for the life of the fan.

Should your fan be fitted with grease nipples, the following instructions should be followed:-

RECOMMENDED LUBRICATION INTERVALS

Motor Frame	Working Hours			
	48 rev/sec	24 rev/sec	16 rev/sec	12 rev/sec
160	4000	8000	12000	20000
180-200	3000	7000	12000	16000
225-250	2000	6000	10000	13000
280	1000	5000	8000	13000
315	1000	3500	8000	10000

Maximum interval 12 months.

These times are a guide only and will depend on the motor manufacturer and actual running conditions.

RECOMMENDED GREASES

Wherever possible the grease used should be identical to the original. When different greases are mixed, even if they are both suitable for the conditions, incompatibility can occur and result in rapid bearing failure.

In the absence of specific instructions supplied with the fan the following greases should be used. STANDARD FANS Shell Alvania R3 or compatible lithium-based grease suitable for 130°C continuous operation. SMOKE SPILL and high temp motors must use the grease stated on the motor to maintain the Smoke Spill approval.

PROCEDURE

If the grease lines are not extended to the outside of the case the fan must be electrically isolated for safety before work commences.

Clean the grease nipples with a clean cloth.

Introduce the new grease to all points while the fan is rotating until the old grease is purged from the grease relief port normally located at the bottom of the bearing housing. If it is required to manually rotate the impeller, the fan must be electrically isolated to prevent accidental startup.

WARNING

INCOMPATIBLE GREASE, EXCESSIVE GREASE OR INCORRECT GREASE RELIEF CAN CAUSE DAMAGE TO THE MOTOR.